

VGA Driver Install For 878p,888p

1. SUN VGA Patch description:

For M64 (ATI RageM1 VGA chip): 108606 (for sol8) & 112622 (for sol9)

For XVR-100 (ATI Radeon7000 VGA chip): 114537 (for sol8) & 114538 (for sol9)

2. How to check my VGA type

```
# prtconf -F (This command could check type of VGA chip)
```

3. Install Instruction for Sun's patch:

a. Download latest m64 & XVR-100 patch as upon from <http://sunsolve.sun.com/pub-cgi/show.pl?target=patchpage>

b. Login as root.

c. Change directory to the directory that you download Sun VGA patch then install the patch.

For example if you download patch to /export/home:

```
# cd /export/home
```

```
#unzip patch.zip
```

```
# patchadd patch
```

d. Reboot the machine

4. Adjust LCD resolution

Use "m64config" (for M64) or "fbconfig" (for XVR-100) command to adjust LCD resolution.

a. m64config:

```
#m64config - prconf (This command could browse all the resolution option supported by the system and browse VGA setting status)
```

#m64config - res 1280x1024x60 nocheck -depth 24 (This command could set 1280x1024x60 resolution)

b . fbconfig :

fbconfig - res \? (This command could browse all the resolution option supported by the system)

fbconfig - prconf (This command could browse VGA setting status)

fbconfig - res 1400x1050x60 nocheck -depth 24 (This command could set 1400x1050x60 resolution)